

THE WEEK

ABPUT THESE PLANS

On this first page you will see above the project complete. On the last page you'll find the finished outer dimensions. Be sure to read ALL of the project steps before you start.

To the right is a list of the Lumber, Hardware/Supplies, and Tools you will need to complete this project. A measuring tape and pencil are not included because that should be pretty standard and self explanatory.

Below What You'll Need is the Parts list. This also is included on the <u>Cutting Diagram</u> page, which is the next to last page of this plan document.

Throughout these plans you'll find the icons below:



This indicates a diagram detailing the dimensions of a project part and/or the placement for pocket holes, screws, nails, etc.



Notes are the instructions for a particular step/section of the project.

STAKE CARE! This indicates when to pay close attention to the diagram close attention to the diagrams, take precautions for safety, etc.

EMPRE PLANS Want more Chief's Shop plans? Visit chiefs-shop.com and look through the Plans section. Be sure to "Like" Chief's Shop on facebook by heading over to

facebook.com/ChiefsShop

Check out Chief's Shop Videos on YouTube. (click here)




LUMBER 1 - 3/4" x 4 x 4 sheet of plywood (yields 2) (4 x 8 sheet yields 4)

(availabilitywillvary)

HARDWARE/SUPPLIES 1 1/4" pocket hole screws wood glue pocket hole plugs/wood filler paint, stain, polyurethane, or sealer

ools

table saw or circular saw miter saw, jig saw sander/belt sander drill/driver " Forstner bit Kreg Pocket Hole Jig clamps square






© Chris Hill/Chief's Shop 2016

Page 1




back












Position the parts as shown and attach using 1-1/4" pocket hole screws.

seat









Use the layout to create the seat. Set your pocket hole jig and drill bit for 3/4" stock for drilling the pocket holes.






SNPTE Use the layout to create the stretcher. Set your pocket hole jig and drill bit for 3/4" stock for drilling the pocket holes.








Position the parts as shown and attach using 1-1/4" pocket hole screws.





CUTTING DIAGRAM



TAKE CARE!

Follow ALL SAFETY GUIDELINES AND RECOMMENDATIONS provided by the manufacturers of your tools, and any chemicals such as glue and finishes you use in this project. YOU are responsible for your safety, so use common sense when working in the shop!

CHIEFS-SHPP.CPM