



WĦAT YOU'LL NEED



LUMBER

- 1 1 x 2 x 4 2 1 x 8 x 8 1 1 x 8 x 10

(availability will vary)

HARDWARE/SUPPLIES
1 1/4" pocket hole screws
1 1/4" wood screws wood glue pocket hole plugs/wood filler paint, stain, polyurethane, or sealer

table saw or circular saw miter saw, jig saw sander/belt sander drill/driver Kreg Pocket Hole Jig clamps square

ABOUT THESE PLANS

On this first page you will see above the project complete. On the last page you'll find the finished outer dimensions. Be sure to read ALL of the project steps before you start.

To the right is a list of the Lumber, Hardware/Supplies, and Tools you will need to complete this project. A measuring tape and pencil are not included because that should be pretty standard and self explanatory.

Below What You'll Need is the Parts list. This also is included on the <u>Cutting Diagram</u> page, which is the next to last page of this plan document.

Throughout these plans you'll find the icons below:



This indicates a diagram detailing the dimensions of a project part and/or the placement for pocket holes, screws, nails, etc.



Notes are the instructions for a particular step/section of the project.



close attention to the diagrams, take precautions for safety, etc.



Want more Chief's Shop plans? Visit chiefs-shop.com and look through the Plans section. Be sure to "Like" Chief's Shop

on facebook by heading over to facebook.com/ChiefsShop.




Check out Chief's Shop Videos on YouTube. (click here)




back legs (2) $- 3/4 \times 7-1/4 \times 33$ front legs (2) - 3/4 x 7-1/4 x 17 **bottom back slat** $- 3/4 \times 7-1/4 \times 30$ **mid back slat** $- 3/4 \times 7-1/4 \times 30$ top back slat $- 3/4 \times 3-1/2 \times 14$ front seat slat $- 3/4 \times 7-1/4 \times 35-1/2$ back seat slat - 3/4 x 7-1/4 x 30 **seat support** $- 3/4 \times 7 - 1/4 \times 30$ stretcher - 3/4 x 7-1/4 x 30 end slats (4) - 3/4 x 1-1/2 x 7-1/4

All parts are listed in actual dimensions. Refer to the Cutting Diagram on the last page of this plan as a guide for determining the specific board from which to cut the parts










Position the parts as shown and attach using 1-1/4" pocket hole screws.










30"





Use the layouts to create the bottom back slat, mid back slat and top back slat. Set your pocket hole jig and drill bit for 3/4" stock for drilling the pocket holes.







Position the parts as shown and attach using 1-1/4" pocket hole screws.

3/4"











Use the layout to create the front seat slat and back seat slat. Set your pocket hole jig and drill bit for 3/4" stock for drilling the pocket holes.






Position the parts as shown and attach using 1-1/4" pocket hole screws.












Position the parts as shown and attach using 1-1/4" pocket hole screws.








Position the parts as shown and attach using 1-1/4" pocket hole screws. Repeat on the other side.






CUTTING DIAGRAM









Follow ALL SAFETY GUIDELINES AND RECOMMENDATIONS provided by the manufacturers of your tools, and any chemicals such as glue and finishes you use in this project. YOU are responsible for your safety, so use common sense when working in the shop!